

## THE USE OF CAPA<sup>®</sup> POLYMERS AS PLASTICISERS

### INTRODUCTION

The low Tg of polycaprolactones, -60°C, leads to their use in a wide variety of polymers where the Capa<sup>®</sup> polymer is reacted with other products to produce an internally plasticised polymer.

Capa<sup>®</sup> Polycaprolactones when blended with compatible polymers, such as PVC, act as external plasticisers. The data presented here details the plasticising effect of Capa<sup>®</sup> PL1000 and Capa<sup>®</sup> 6500, and compares their performance with other commonly used non-migrating or polymer plasticisers with DOP as a reference.

Capa<sup>®</sup> PL1000 is a 1000 molecular weight soft waxy polymer at 20°C and Capa<sup>®</sup> 6500 is a hard crystalline thermoplastic, molecular weight 50,000 and is supplied as a granule.

### PROCESSING

A standard formulation based on Solvic 271GC was used in all cases. The blends were mixed for 10 minutes at 180°C on a Brabender and pressed into sheets.


The comparative plasticisers were:

DOP:	Diocetyl phthalate
TOTM:	Tri octyl trimellitate
Citrate:	n butyl tri n hexyl citrate
Palamoll 651:	Polyadipate

### ELASTIC MODULUS AT ROOM TEMPERATURE


The elastic modulus was measured at 1 mm/minute. The distance between the bits was 50 mm and the segment modulus considered was 0.05% and 0.25% of deformation.

Rigid PVC was the reference and gave a modulus of 2000 MPa.



## STRAIN AT BREAK

The values were measured at 100 mm/minute.




## DMTA






DMTA is used to show the evolution of elastic modulus ( $E'$ ) against temperature and also to compare the glass transition temperature,  $T_g$ , of the different formulations.

The values were generated with a bending frequency of 1 Hz in the temperature range  $-50^\circ\text{C}$  to  $200^\circ\text{C}$ .

The effect of  $T_g$  on  $E'$  is clear with values for all blends being relatively constant below the  $T_g$ . Above the  $T_g$  the behaviour of  $E'$  is dependent on the plasticiser.

For all plasticisers  $E'$  decreases with increasing plasticiser content unless there is a separation issue, such as crystallisation of the plasticiser.





In general, the characteristics of polycaprolactones offer a range of options for plasticisation of polymer resins and particularly PVC. The low Tg of Capa® polymers, compatibility with PVC across a wide range of addition levels and molecular weights, enables a formulation of resins based on Capa® polycaprolactones with varied modulus and viscosity.

**For further information please contact:**

Perstorp UK Limited  
Baronet Road  
Warrington  
Cheshire WA4 6HB  
United Kingdom

Telephone: +44 (0) 1925 643210  
Fax: +44 (0) 1925 232207  
E-mail: [contact.capa@perstorp.com](mailto:contact.capa@perstorp.com)  
Website: [www.perstorpcaprolactones.com](http://www.perstorpcaprolactones.com)

The information given in this data sheet is given as a general guide and should not be taken to cover all cases. Each customer should ensure that the product concerned is suitable for the specific purpose and the manner in which it is intended to be used. The information given must not be taken in any way to form a specification. This data sheet does not form part of the Conditions of Sale of our products and is of a general nature.

**FREEDOM FROM PATENT RESTRICTIONS SHOULD NOT BE ASSUMED**